



Karaoke Connection Instructions

--Plug player into wall with power cord.

--For the audio, run the dual RCA cable from the red and white outputs that say left and right on the back of the player, into the red and white RCA inputs on the PA head.

--For the video, run the single RCA cable from the yellow video output on the back of the player, into the yellow video input on the TV.

--The microphones will plug into the front of the Karaoke player where it says mic 1 and 2.

--You can control the player with the remote. Queue up the songs by entering the number that corresponds with the song you want and pushing the right arrow button. Play the songs by pushing the play button.

--For the PA, there should be two speaker cables and a power cord in the back compartment of the passport.

--Plug into wall and run the two speaker cables from the speaker outputs on the back of the mixer into each of the speakers.

--It is best to turn the main master volume knob up, and then adjust the volume on the channel you are plugged into until the volume is loud enough.