



The Karaoke Channel Connection Instructions

--Plug PA System into wall with power cord.

--For the audio, run the auxiliary cable (1/8" or 3.5mm) from your computer to the Fender PA System - Stereo Input.

--For the video, run a VGA Cable from your computer to the video monitor.

Note: Mac computers require an additional adapter to convert to VGA.

Setup for your video output on PC's may require an additional step - usually this is the 'FN' button on your keyboard + the F8 key (look for the F-Button that has either "LCD/CRT" or two rectangles).

--For the PA, the two speaker cables and a power cord are in the back compartment of the passport.

--Plug into wall and run the two speaker cables from the speaker outputs on the back of the mixer into each of the speakers.

--It is best to turn the main master volume knob up, and then adjust the volume on the channel you are plugged into until the volume is loud enough.

--The microphones will plug into the front of the Fender Passport on Channel 1 and Channel 2 with the mic cables. Turn the volume on each mic to desired level.

--Once your Audio/Video is working and your Karaoke Channel account is active, queue songs in the player - use the fullscreen button to enhance your experience.